





READ MANUAL BEFORE INSTALLATION

USE LOOP FOR BUBBLERS AT SAME DEPTH



USE INDIVIDUAL VALVES FOR BUBBLERS AT DIFFERENT DEPTHS



FOR MORE INFORMATION, CALL TECHNICAL SUPPORT AT (908) 355-7995